



DUAL SACK TRUCK

Model No: 5535804



USER INSTRUCTIONS

GENERAL SAFETY PRECAUTIONS


⚠ WARNING!: read these instructions before using the equipment

- **BEFORE** attempting to transport any load, ensure you are physically able to do so.
- **DO NOT** exceed the maximum working load for the sack truck 200kg.
- **DO NOT** allow children to play with or ride in the sack truck.
- **NEVER** use the sack truck if any of the tyres are deflated.
- **NEVER** use the sack truck to transport personnel or animals.
- **ALWAYS** inspect the sack truck for signs of wear or damage before use.
- **ALWAYS** ensure the load is evenly distributed and is perfectly stable.

ASSEMBLY

• WHEELS

1. Ensure each axle is clean from dust and dirt to allow free movement of the wheel.
2. Slide the wheel (Fig.1.2) onto the axle (Fig.1.1), followed by the washer (Fig.1.3) and complete by pushing the split pin (Fig.1.4) through the hole in the end of the axle and bending over to retain.
3. Repeat for the other side.



TECHNICAL SPECIFICATION

GENERAL:

Description:Dual Sack Truck
 Part No:5535804
 Use:Industrial

Product Specification:

Material:Steel
 Product Dimensions (H X W X L):1450x550x460mm
 Product Weight:11.8kg
 Toe Plate Size (W X L):352x215mm
 Maximum Capacity:200kg
 Wheel Diameter:Pneumatic Tyre10"x3.50"-4"
 Max Tyre Pressure:30PSI