



STAIR SACK TRUCK

Model No: 5535805




USER INSTRUCTIONS

GENERAL SAFETY PRECAUTIONS

- ⚠ WARNING!:** read these instructions before using the equipment
- **BEFORE** attempting to transport any load, ensure you are physically able to do so.
 - **DO NOT** exceed the maximum working load for the sack truck 150kg.
 - **DO NOT** allow children to play with or ride in the sack truck.
 - **NEVER** use the sack truck if any of the tyres are deflated.
 - **NEVER** use the sack truck to transport personnel or animals.
 - **ALWAYS** inspect the sack truck for signs of wear or damage before use.
 - **ALWAYS** ensure the load is evenly distributed and is perfectly stable.

ASSEMBLY

- **WHEELS**
1. Ensure each axle is clean from dust and dirt to allow free movement of the wheel.
 2. Slide the wheel (Fig.1.2) onto the axle (Fig.1.1), followed by the washer (Fig.1.3) and complete by pushing the split pin (Fig.1.4) through the hole in the end of the axle and bending over to retain.
 3. Repeat for the other side.



TECHNICAL SPECIFICATION

GENERAL:
Description:Stair Sack Truck
Part No:5535805
Use:Industrial

Product Specification:
Material:Steel
Product Dimensions (H X W X L):1300x517x595mm
Product Weight:14.5kg
Toe Plate Size (W X L):310x255mm
Maximum Capacity:150kg
Wheel Diameter:Solid Tyre 6" Wheel Kit